


RGB controller



Auto pisy366Modes

Power/Play pause

10 levels speed adjust

S+ :Speed+
S- :Speed-

366 Kinds mode switching

M+ :Mode+
M- :Mode-

these buttons, light strip displays its corresponding colors

Press 5 seconds,remote controls are one to one matching (only this remotecontrol can control it)

In the off state press this button to enter the setup menu,then press the M+orM- to sdjust LED pixels.Press the blue button to sdjust the RGB sequence.After complete setting,press Off to save/exit

Shutdown
Auto save when shutdown

Brightness+

Brightness adjustment (32levels)

Brightness -

RGB sequence sdjustment function In the state of shutdown,press the AUTO to enter the setup menu.Now,the first three lights of LED strip display the current RGB sequence. Press this button to adjust the RGB sequence until lights are red,green and blue.Then press the Off button to save.

Press 5 seconds to cancel the remote control matching.All remote controls can control it.

Controlador RGB



Modo Auto

Encender/Reproducir/Pause

Ajuste de velocidad de 10 niveles

S+ :Velocidad +
S- :Velocidad -

Cambio de modo de 366 tipos

M+ :Modo+
M- :Modo-

Estos botones, tira de luz muestra su correspondiente colores

Presione 5 segundos, controles remotos son uno a uno (solo este control remoto puede controlarlo)

En el estado apagado, presione este botón para ingresar el menú de configuración, luego presione M + o M- para ajustar los píxeles del LED. Presione el botón azul para ajustar la secuencia RGB. Después de completar configuración, presione Off para guardar / salir

Apagar
Guardado automático cuando se apaga

Brillo +

Ajuste de brillo (32 niveles)

Brillo -

Función de ajuste de secuencia RGB En el estado de apagado, presione AUTO para ingresar el menú de configuración. Ahora, las tres primeras luces de la tira de LED muestra la secuencia RGB actual. Presione este botón para ajustar la secuencia RGB hasta que las luces sean rojas, verdes y azules. Luego presione el botón Off para guardar.

Presione 5 segundos para cancelar el control remoto coincidencia Todos los controles remotos pueden controlarlo.